


STÜHRLING ORIGINAL L.L.C.

INSTRUCTION FOR ADJUSTING THE STRAP LENGTH (FOR DEPLOYMENT CLASP)



1 Buckle in Closed Condition.



2 To open the buckle
Use your thumb and pull
the bottom flap and Top
flap in opposite direction.



3 Buckle in Open Condition.



4 # Place to insert the Strap in the Buckle.



5 Put the Strap inside the Buckle.
Strap can be moved up & down to arrive at
at the correct length.



6 Close the bottom flap of the buckle with
your thumb such that the tongue enters
the hole in the Strap. A click sound confirms
the bottom flap is locked.



7 Strap with the Buckle in Closed Condition.