

WATER RESISTANT

D

Your new watch is a water-resistant watch. Check the marking on the back of the watch, find below the relevant usage recommendation.

- **Water Resistant 3ATM OR 30M (100 Feet)**
Shall with stand splashes of water while washing the hand. But should not be worn while swimming or diving.
- **Water Resistant 5ATM or 50M (165 Feet)**
Suitable for showering or swimming in shallow water.
- **Water Resistant 10ATM or 100M (330 Feet)**
Suitable for swimming, snorkeling, but should not be worn while scuba diving.
- **Diver's 20ATM or 200M (660 Feet)**
Meets the higher requirements of water resistant and suitable for scuba diving. We don't recommend swimming or diving with your watch unless it has a screw down crown and is water resistant to at least 10ATM or 100 Meters)

GENERAL CARE FOR A WATER RESISTANT WATCH

E

- DO NOT OPERATE ANY BUTTONS WHEN THE WATCH IS WET OR IN WATER.
- DO NOT WEAR THE WATCH IN A HOT SHOWER OR SAUNA. EXTREME HEAT CAN DAMAGE THE WATCH.
- AFTER USE IN SALT WATER OR CONTACT WITH SAND OR MUD, RINSE THE WATCH IN A STREAM OR FRESH WATER AND DRY IT WITH SOFT CLOTH.
- LEATHER STRAPS ARE MORE EASILY DAMAGED BY FREQUENT EXPOSURE TO WATER. AFTER EVERY USE IN WATER, WIPE THE STRAP WITH A SOFT CLOTH, TO IMPROVE THE LIFE OF THE STRAP.

IMPORTANT

THIS WATCH IS EQUIPPED WITH AN AUTOMATIC MOVEMENT, WITH MANUAL WINDING FUNCTION. THE MOVEMENT IS ENERGIZED BY

- i. Winding the crown (or)
- ii. By the movements of the arm wrist (or)
- iii. By the watch winder

STÜHLING ORIGINAL




INSTRUCTION MANUAL - DT AUTOMATIC DUAL TIME MOVEMENT

CAUTION

DO NOT USE THE QUICK DATE FUNCTION BETWEEN 21:00 HRS TO 03:00 HRS, AS IT WILL DAMAGE THE MOVEMENT MECHANISM.

WATCH DISPLAY


A

*This watch displays the Local & Home Time (Dual Time) simultaneously.

*The Dual time zone disc rotates on a circular track and keeps the time difference between two time zone.

Crown Position 1 : Winding position
Crown Position 2 : To set Quick Date & 2nd Time
Crown Position 3 : To set the Time

CORRECTION MODE

B


QUICK DATE SETTING - CROWN POSITION 2

Gently pull the crown to position 2 and rotate the crown forward to set the date.

TIME SETTING - CROWN POSITION 3

Gently pull the crown to the position 3 and rotate the crown forward to set the time.

SET 2ND TIME ZONE

C

CROWN POSITION 2

- *Gently pull the Crown to the position 2.
- *Rotate the Crown back wards, which inturn rotates the small disc.
- *Keep rotating the crown till the small disc completes a full rotation and get positioned vertically at 12H.
- *Now the time on the small dial is set 1hr behind.
- *Continue to do the same for total difference in hours, of your local time.

As the disc can only be rotated in one direction, for setting the time for time zone ahead, the above procedure to be continued till the desired time difference is reached.