

WATER RESISTANT

D

Your new watch is a water-resistant watch. Check the marking on the back of the watch, find below the relevant usage recommendation.

Water Resistant 3ATM OR 30M (100 Feet)

Shall with stand splashes of water while washing the hand. But should not be worn while swimming or diving.

Water Resistant 5ATM or 50M (165 Feet)

Suitable for showering or swimming in shallow water.

Water Resistant 10ATM or 100M (330 Feet)

Suitable for swimming, snorkeling, but should not be worn while scuba diving.

Diver's 20ATM or 200M (660 Feet)

Meets the higher requirements of water resistant and suitable for scuba diving.

We don't recommend swimming or diving with your watch unless it has a screw down crown and is water resistant to at least 10ATM or 100 Meters)

GENERAL CARE FOR A WATER RESISTANT WATCH

E

- * DO NOT OPERATE ANY BUTTONS WHEN THE WATCH IS WET OR IN WATER.
- * DO NOT WEAR THE WATCH IN A HOT SHOWER OR SAUNA. EXTREME HEAT CAN DAMAGE THE WATCH.
- * AFTER USE IN SALT WATER OR CONTACT WITH SAND OR MUD, RINSE THE WATCH IN A STREAM OR FRESH WATER AND DRY IT WITH SOFT CLOTH.
- * LEATHER STRAPS ARE MORE EASILY DAMAGED BY FREQUENT EXPOSURE TO WATER. AFTER EVERY USE IN WATER, WIPE THE STRAP WITH A SOFT CLOTH, TO IMPROVE THE LIFE OF THE STRAP.

IMPORTANT

THIS WATCH IS EQUIPPED WITH AN AUTOMATIC MOVEMENT, WITH MANUAL WINDING FUNCTION.

THE MOVEMENT IS ENERGIZED BY

- i. Winding the crown (or)
- ii. By the movements of the arm wrist (or)
- iii. By the watch winder

DO NOT SET THE DUAL TIME FUNCTION BETWEEN :50 TO :10 MINS OF EVERY HOUR.


STÜHRLING ORIGINAL



INSTRUCTION MANUAL - O

AUTOMATIC GRAND DATE DUAL TIME MOVEMENT

WATCH DISPLAY

A

CROWN POSITION 1


Winding Position, watch runs

CROWN POSITION 2 - Quick Date Change

Gently pull the Crown to this position
Rotate the Crown forward to Set the date.

* DO NOT USE THE QUICK DATE FUNCTION BETWEEN 21:00HRS AND 4:00HRS, AS IT WILL DAMAGE THE INTERNAL PARTS OF THE MOVEMENT.

CORRECTION MODE


B

CROWN POSITION 3 - Time Setting

Gently pull the Crown to this position
Rotate the Crown forward to Set the time and date by passing through mid-night

The Home Time indicator is synchronized with the local time. When the crown is rotated in forward direction (Position 3) for every 1hr passing of hour and minute hand the home time indicator advances by an hour.

SET 2ND TIME ZONE

C

EXAMPLE

To set the home Time 2hrs behind Local Time

CROWN POSITION 3

Gently pull the Crown to this position
Rotate the Crown backward to move the hands anti-clockwise until, the desired time (-2 Hrs) difference is reached. (see picture above)

Push the crown back to normal position(1)

Now the watch displays 2 time zones with a difference of 2 Hrs.